



Dome Light User Guide

This guide has been written to help you get the most from your Dome Light. Please ensure that you read this fully as it contains important information on setting up your Dome Light. Failure to follow this advice may result in damage to the Dome Light and invalidate your warranty.

Keep this guide in a safe place for future reference.



Unpacking

1. The Dome Light is shipped in specialist packaging, designed to protect it from damage during transport.
2. Ensure that Dome Light is carefully removed from the out packaging. Keep the packaging in case the Dome Light needs to be returned.
3. If you find any damage when you unpack you should report it within **7 days** to your supplier.

Setting up

1. The Dome Light can either be mounted to the ceiling or wall depending on your requirements.
2. The Dome Light must be attached to a **solid** wall using fixings appropriate to the construction of the wall.
3. Attach the Dome Light using the 4 brackets constructed on the Dome Light itself. Remember to place your power supply appropriately to suit your requirements for installation.
4. Ensure that the power supply is sited at an adequate distance from the Dome Light and that there is no tension in the power cable. The power cable should never be coiled around the power supply as this may cause it to overheat and malfunction.
5. The Dome light is now ready to use.

Potential risks & warnings

1. Read and understand all these instructions before using the Dome Light.
2. Situate the Dome Light slightly away from the end user if placed on the ceiling.
3. Never stare directly into the middle of the Dome Light when the unit is turned on. LED's emit a large amount of light which could be damaging to the eyes.
4. Do not operate the Dome Light with a damaged power cord, or if it has been dropped or damaged.
5. Position the power cord so that it will not be tripped over, pulled or come into contact with hot surfaces.
6. If an extension lead is necessary, a cable with a current rating at least equal to that of the Dome Light (1A) should be used.
7. Always connect the Dome Light source to a grounded outlet.
8. To reduce the risk of electrical shock, do not immerse the product in water or other liquids.
9. Do not dismantle the Dome Light, contact the supplier or manufacturer if servicing is required. Incorrect assembly can cause electrical shock when the product is used.
10. If using a power supply other than the one supplied, it should always follow these specifications: 12V AC, 1000mA, 2.1mm plug, centre positive.

This Dome Light is supplied by:



Manufactured by:

Apollo Creative
Knaresborough Technology Park
Manse Lane
Knaresborough
North Yorkshire
HG5 8LF

T: 01423 798232

F: 01423 798239

E: sales@apollocreative.co.uk

W: www.apollocreative.co.uk

